

The SHADEMASTER™

Installation Sheet 6' x 9' Feuille d'installation

| | |
|--------------------|-------------|
| PEAK | B |
| PEAK | R (4 poles) |
| EAVES (short side) | S + T |
| EAVES (long side) | G + H |
| LEGS | L + M |

COMPONENTS

| | |
|------------------------|-------------------|
| ¾" LONG PEAK.....1 | B |
| Plastic Corners4 | Q |
| ¾" Tubing4 | R |
| 1" Tubing8 | (G + H) & (S + T) |
| 1 ¼" Tubing8 | (L + M) |
| Metal Hooks4 | N |
| Plastic Caps4 | O |
| Shade Cover1 | |

ASSEMBLY (no tools required)

1. Assemble the perimeter with the 1" tubing G + H long side
S + T short side
And join to 4 plastic corners
2. Create the roof with 4 "R" poles and the long peak "B"
3. Insert top portion of the leg using the plain 1 ¼" tubes "M"
4. Lay the cover over the half-raised structure slipping it over the corners.
5. Insert the bottom part of the leg "L"
6. Secure the cover to the leg using the upper loop on the cover with the hooks
7. Secure using the tent pegs for temporary use or purchase our tie-down kit for longer use on wood deck or cement.

COMPOSANTES

| |
|----------------------------|
| ¾" Pignon double 1 |
| Coins de Plastique4 |
| Tubes de ¾"4 |
| Tubes de 1"8 |
| Tubes de 1 ¼"8 |
| Petits crochets.....4 |
| Capuchons de plastique ..4 |
| Toile d'ombrage1 |

ASSEMBLAGE (pas d'outils requis)

1. Assemblez le perimetre avec les tubes de 1" G + H long
S + T court
Et joindre aux 4 coins de plastique
2. Assemblez le toit avec 4 poteaux "R" et le pignon "B"
3. Inserez la partie superieure des jambes avec les poteaux "M"
4. Placez la toile sur la structure maintenant et glissez la toile par-dessus les coins.
5. Inserez la partie inferieure de la jambe "L"
6. Attachez la toile aux poteaux avec la gance superieure et les crochets
7. Securisez temporairement avec les piquets de tente ou achetez le kit d'ancrage pour patio de bois ou ciment.